

Audi RS3 8Y (2025-) Front Canard Install

STEP 1: Prepare Canards [optional]

Optionally before installing the canards, we recommend painting or wrapping the canards in black or carbon fiber vinyl. Start with 120 grid working to 600 grid before painting or wrapping. Wrapping will be the quickest option delivering stunning results as shown.



STEP 2: Clean Surface

Prior to the install wash the surface using any generic product. Following this use a piece of kitchen towel and cleaning alcohol to deep clean the surface before applying the canards, this will ensure a secure bond between the canards and the car.



STEP 3: Apply Tape

Now apply the 3M tape supplied in the box to the canards as shown, cut off any tape as needed.



STEP 4: Align and Fit

Before installing the canards test fit them on the vehicle using household/painters' tape to align and mark the perfect fitment.

Now that the canards are ready to fit remove the tape backing and place them on the car, make sure to apply pressure when doing so. Keep applying pressure for approx. 2 minutes to guarantee the best bond. Repeat steps 3-6 for all canards.

